



Auxiliary Contacts



For Use With Switchfuses

Part No.	Contact Configuration	Compatible with	Qty
063AUX1/1SF	1NO/1NC	32-63A switch fuse	1
063AUX2/2SF	2NO/2NC	32-63A switch fuse	1
160AUX1/1SF	1NO/1NC	100-160A switch fuse	1
160AUX2/2SF	2NO/2NC	100-160A switch fuse	1
400AUX1/1SF	1NO/1NC	200 - 400A switch fuse	1
400AUX2/2SF	2NO/2NC	200 - 400A switch fuse	1
800AUX1/1SF	1NO/1NC	630 - 800A switch fuse	1
800AUX2/2SF	2NO/2NC	630 - 800A switch fuse	1

Specifications //

- Auxiliary Contacts - For remote indication and alarms

For Use With Enclosed Switch Disconnectors

Part No.	Contact Configuration	Compatible with	Qty
160AUX1/1	1NO/1NC	160A isolator	1
160AUX2/2	2NO/2NC	160A isolator	1
315AUX1/1	1NO/1NC	200 - 315A isolator	1
315AUX2/2	2NO/2NC	200 - 315A isolator	1
800AUX1/1	1NO/1NC	400 - 800A isolator	1
800AUX2/2	2NO/2NC	400 - 800A isolator	1
3150AUX1/1	1NO/1NC	1000 - 3150A isolator	1
3150AUX2/2	2NO/2NC	1000 - 3150A isolator	1

For Use With Enclosed Manual Changeover Switches

Part No.	Contact Configuration	Compatible with	Qty
160AUX1/1MC	1NO/1NC	160A manual changeover switch	1
160AUX2/2MC	2NO/2NC	160A manual changeover switch	1
800AUX1/1MC	1NO/1NC	315-800A manual changeover switch	1
800AUX2/2MC	2NO/2NC	315-800A manual changeover switch	1